### How to design masonry structures using Eurocode 6 2. Vertical resistance

Eur Ing, Prof. J J Roberts BSc(Eng), PhD, CEng, FIStructe, FICE, FIMS, FCMI, MICT O Brooker BEng, CEng, MICE, MIStructe

### Introduction

The introduction of European standards to UK construction is a significant event. The ten design standards, known as the Eurocodes, will affect all design and construction activities as current British standards for design are due to be withdrawn in March 2010.

This publication is part of a series of three guides entitled *How to design masonry structures using Eurocode 6*. The aim is to make the transition to Eurocode 6, *Design of masonry structures* as easy as possible by drawing together in one place key information and commentary required for the design of typical masonry elements.

The Concrete Centre and the Modern Masonry Alliance recognised that effective guidance is required to ensure that the UK design profession is able to use Eurocode 6 quickly, effectively, efficiently and with confidence. Therefore a steering group, with members from across the masonry industry (see back cover for a list of members), was established to oversee the development of these guides.



### Guidance for vertical resistance

This guide is the second in a series of three giving guidance on the design of masonry structures to Eurocode  $6^1$ . The first guide, *Introduction to Eurocode*  $6^2$  gives an introduction to design and assessment of actions using Eurocode 6 and also covers the specification and execution (workmanship) of masonry. This guide explains how to design for vertical actions and determine vertical resistance. The third guide in the series<sup>3</sup> covers the design of laterally loaded masonry panels. Throughout this guide the Nationally Determined Parameters (NDPs) from the UK National Annexes (NAs) have been used. These enable Eurocode 6 to be applied in the UK.

### Design procedure

This guide explains how to determine the design resistance for a vertically loaded wall. The first guide in the series, *Introduction to Eurocode 6*, should be referred to so that the design load can be determined. In essence, when using the Eurocodes the designer should check that the resistance is greater than or equal to the effect of the actions. A flow chart for the design of masonry walls to resist vertical actions is shown as Figure 1.

### Compressive strength

Eurocode 6 introduces some new concepts when dealing with the design of masonry for vertical loads. The first of these relates to the way the compressive strength of the masonry units is expressed. For design purposes the normalized compressive strength,  $f_{\rm b}$ , of the masonry units is used. This is the compressive strength of the units converted to the air-dried compressive strength of an equivalent 100 mm wide by 100 mm high masonry units. The detail is contained in Part 1 of BS EN 772, *Methods of test for masonry units*<sup>4</sup>. The advantage to the designer is that the normalized strength is independent of the size and shape of the units used in the final construction.

### Grouping of masonry units

The second change relates to the way in which masonry units are classified. This is dealt with by grouping masonry into one of four groups as shown in table 3.1 of Eurocode 6. The group designation will normally be declared by the manufacturer. The designation depends upon the volume and direction of holes in the unit and the thickness of webs and shells. Historically only Group 1 and Group 2 units have been used in the UK, and values for these groups only are given in the UK NAs.





### The characteristic compressive strength of masonry

The characteristic compressive strength of masonry (other than shell bedded masonry) is determined from the results of tests in accordance with BS EN  $1052-1^5$ . The tests are carried out on small wallette specimens rather than the storey-height panels used in the past. The designer has the option of either testing the units intended to be used in a project or using the values determined from a database. Values from a large database are provided in the UK NA to Eurocode 6, Part 1-1 in the form of the constants to be used in the following equation:

### $f_{\rm k} = K f_{\rm b}^{\ \alpha} f_{\rm m}^{\ \beta}$ [Equation (3.1) of Eurocode 6, Part 1–1]

where

- $f_k$  = characteristic compressive strength of the masonry, in N/mm<sup>2</sup>
- K = constant see Table 1 and Figure 2
- $\alpha$ ,  $\beta$  = constants see Table 2
- $f_{\rm b}$  = normalized mean compressive strength of the units, in the direction of the applied action effect, in N/mm<sup>2</sup>
- $f_{\rm m}$  = compressive strength of the mortar, in N/mm<sup>2</sup>

For blocks laid flat, table 8 of the National Annex to Eurocode 6, Part 1–1 contains a specific value for K to be used in Equation (3.1) of Eurocode 6, Part 1–1.

The following limitations are placed on Equation (3.1):

- The masonry is detailed and constructed in accordance with the requirements of BS EN 1996–1–1, section 8.
- $f_b$  is taken to be not greater than 110 N/mm<sup>2</sup> when units are laid in general purpose mortar and 50 N/mm<sup>2</sup> when laid in thin layer mortar ( $f_b$  is determined in the normal direction of loading).
- *f*<sub>m</sub> is taken to be not greater than 2*f*<sub>b</sub> nor greater than 12 N/mm<sup>2</sup> when units are laid in general purpose mortar or 10 N/mm<sup>2</sup> when units are laid in lightweight mortar.
- The coefficient of variation of the strength of the masonry unit is not more than 25%.

For masonry made with general purpose mortar, adjustments are made to the value of K as shown in Figure 2.

In addition the following points should be noted:

For masonry made of general purpose mortar where Group 2 and Group 3 aggregate concrete units are used with the vertical cavities filled completely with concrete, the value of  $f_b$  should be obtained by considering the units to be Group 1 having a



#### Figure 1 Flow chart for the design of masonry walls to resist vertical actions

compressive strength corresponding to the compressive strength of the units or of the concrete infill, whichever is the lesser.

Where action effects are parallel to the direction of the bed joints, the characteristic compressive strength may be determined from Equation (3.1) with  $f_b$  derived from BS EN 772–1, where the direction of application of the load to the test specimens is in the same direction as the direction of the action effect in the masonry, but with the shape factor,  $\delta$ , as given in BS EN 772–1 taken to be no greater than 1.0. For Group 2 and 3 units, *K* should then be multiplied by 0.5.

#### Table 1

#### Values of K to be used with Equation (3.1)

Masonry unit	General purpose	Thin layer mortar (bed	Lightweight mortar of density	
	mortar joint ≥ 0.5 mm and ≤ 3 mm)		600 ≤ ρ <sub>d</sub> ≤ 800 (kg/m³)	800 < <i>p</i> <sub>d</sub> ≤ 1300 (kg/m³)
Clay				
Group 1	0.50	0.75	0.30	0.40
Group 2	0.40	0.70	0.25	0.30
Group 3	_ a	_ a	_ a	_ a
Group 4	_ a	_ a	_ a	_ a
Calcium silicate				
Group 1	0.50	0.80	_ b	_ b
Group 2	0.40	0.70	_ b	_ b
Aggregate concrete				
Group 1	0.55	0.80	0.45	0.45
Group 1 <b>°</b> (units laid flat)	0.50	0.70	0.40	0.40
Group 2	0.52	0.76	0.45	0.45
Group 3	_ a	_ a	_ a	_ a
Group 4	_ a	_ a	_ a	_ a
Autoclaved aerated concrete				
Group 1	0.55	0.80	0.45	0.45
Manufactured stone				
Group 1	0.45	0.75	_ b	_ b
Dimensioned natural stone				
Group 1	0.45	_ b	- <sup>b</sup>	_ b
Kov				

Key

**a** Group 3 and 4 units have not traditionally been used in the UK, therefore no values are available.

 ${\bf b}$  These masonry unit and mortar combinations have not traditionally been used in the UK, and no values are available.

c If Group 1 aggregate concrete units contain formed vertical voids, multiply K by (100 - n) /100, where n is the percentage of voids, maximum 25%.

#### Note

Where there is a mortar joint parallel to the face of the wall  ${\it K}$  should be modified (see Figure 2).

#### Table 2

#### Values to be used in Equation (3.1)

Type of mortar	Values to be used
General purpose mortar	$\alpha$ = 0.7 and $\beta$ = 0.3
Lightweight mortar	$\alpha$ = 0.7 and $\beta$ = 0.3
Thin layer mortar in bed joints of thickness 0.5 to 3 mm (using clay units of Group 1, calcium silicate units, aggregate concrete units and autoclaved aerated concrete units)	$\alpha$ = 0.85 and $\beta$ = 0
Thin layer mortar in bed joints of thickness 0.5 to 3 mm (using clay units of Group 2)	$\alpha$ = 0.7and $\beta$ = 0

When the perpendicular joints are unfilled, Equation (3.1) may be used, with consideration of any horizontal actions that might be applied to, or be transmitted by, the masonry. (See also Cl. 3.6.2(4) of BS EN 1996–1–1.)

# The characteristic compressive strength of shell bedded masonry

Shell bedding provides two strips of mortar rather than a full mortar bed. It serves to improve rain penetration resistance but reduces the strength of the masonry. A typical shell bedded unit is shown in Figure 3.

For Group 1 and Group 4 units the procedure above may be used to obtain the characteristic compressive strength of the masonry





### Figure 3

Shell bedding



provided that:

- The width of each strip of mortar is at least 30 mm.
- The thickness of the masonry wall is equal to the width or length of the masonry units so that there is no longitudinal mortar joint through all or part of the length of the wall.
- The ratio *g*/*t* is not less than 0.4
- where
  - q = total width of the mortar strips
  - t = the thickness of the wall.
- K is taken as above when g/t = 1.0 or half this value when g/t = 0.4. Linear interpolation may be used for intermediate values.

Groups 2 and 3 may be designed as non-shell bedded masonry provided that the normalized mean compressive strength of the units used in Equation (3.1) is obtained from tests carried out in accordance with BS EN  $772-1^4$  for shell bedded units.

### Effective height

The effective height of a masonry wall is obtained by applying a factor to the clear height of the wall such that:

 $h_{\rm ef} = \rho_{\rm n} h$ 

where

- $h_{\rm ef}$  = effective height of the wall
- h = clear storey height of the wall
- $\rho_n$  = reduction factor, where n = 2, 3 or 4, depending upon the edge restraint or stiffening of the wall

The reduction factor to be applied depends upon the restraint offered by adjoining elements. Masonry walls may be stiffened by a number of rigid structural elements such as floors, roofs and other walls. Stiffening walls should have a length of at least 1/5 of the clear height





and have a thickness of at least 0.3 times the effective thickness of the wall to be stiffened. When the stiffening wall contains openings, the minimum length of wall should be as shown in Figure 4 and the stiffening wall should extend a distance of at least 1/5 of the storey height beyond each opening.

Where a wall is restrained at the top and bottom by reinforced concrete floors or roofs spanning from both sides at the same level or by a reinforced concrete floor spanning from one side only and having a bearing of at least 2/3 of the thickness of the wall then:

#### $\rho_2 = 0.75$

unless the eccentricity of the load at the top of the wall is greater than 0.25 times the thickness of the wall, in which case  $\rho_2 = 1.0$ .

Where the wall is restrained by timber floors or roofs spanning from both sides at the same level or by a timber floor spanning from one side having a bearing of at least 2/3 the thickness of the wall but not less than 85 mm, then:

 $\rho_2 = 1.0.$ 

For walls restrained at the top and bottom and stiffened on one vertical edge, use the value  $\rho_3$  in Figure 5 and where both vertical edges are stiffened, use the value  $\rho_4$  in Figure 6. Note that Equations (5.6), (5.7) and (5.8) in Eurocode 6, Part 1–1 may be used as an alternative to the use of the graphs.

### **Effective thickness**

For a single-leaf wall, a double-leaf wall (with ties at a density of 2.5 per m<sup>2</sup> or greater), a faced wall, a shell bedded wall and a grouted cavity wall, the effective thickness,  $t_{eff}$  is taken as the actual thickness

#### Figure 5 Graph showing values of $\rho_3$



of the wall (t), provided this is greater than the minimum thickness,  $t_{min}$ . The value of  $t_{min}$  for a loadbearing wall should be taken as 90 mm for a single-leaf wall and 75 mm for the leaves of a cavity wall.

For a cavity wall the effective thickness is determined using the following equation:

$$t_{\rm ef} = {}^3\!\sqrt{t_1^3 + t_2^3} \ge t_2$$

where

 $t_1$  = actual thickness of the outer or unloaded leaf

 $t_2$  = actual thickness of the inner or loaded leaf

Note that the effective thickness of the unloaded leaf should not be taken to be greater than the thickness of the loaded leaf and that ties should be provided at a density of 2.5 per  $m^2$  or greater.

When a wall is stiffened by piers the effective thickness is enhanced by using the following equation:

 $t_{\rm ef} = \rho_{\rm t} t$ 

where

 $t_{\rm ef}$  = effective thickness

 $\rho_{\rm t}$  = coefficient obtained from Table 3

t =thickness of the wall

### Slenderness ratio

The slenderness ratio of the wall is obtained by dividing the effective height by the effective thickness and should not be greater than 27 for walls subjected to mainly vertical loading. Note also that the effects of creep may be ignored in walls with a slenderness ratio up to 27.

#### Figure 6

#### Graph showing values of the reduction factor, $ho_4$



### Assessment of eccentricity

When a wall is subjected to actions that result in an eccentricity at right angles to the wall, Eurocode 6 requires the resistance of the wall to be checked at the top, mid-height and bottom. The eccentricity at top or bottom of the wall is:

$$e_{\rm i} = \frac{M_{\rm id}}{N_{\rm id}} + e_{\rm he} + e_{\rm init} \ge 0.05t$$

where

- $M_{\rm id}$  = design value of the bending moment at the top or the bottom of the wall resulting from eccentricity of the floor load at the support
- $N_{\rm id}$  = design value of the vertical load at the top or the bottom of the wall
- $e_{\rm he}$  = the eccentricity at the top or bottom of the wall resulting from the horizontal loads
- $e_{init}$  = initial eccentricity for construction imperfections, which may be taken as  $h_{ef}$ /450, with a sign that increases the absolute value of  $e_i$  and  $e_m$  as appropriate
- t = thickness of the wall

The mid-height eccentricity,  $e_{mk}$ , is:

 $e_{mk} = e_m + e_k \ge 0.05t$ 

where

$$e_{\rm m} = \frac{M_{\rm md}}{N_{\rm md}} + e_{\rm hm} \pm e_{\rm i}$$

 $e_k = 0$ , when the slenderness ratio  $\leq 27$  (ie. ignoring creep)

- $M_{md}$  = design value of the greatest moment at the mid-height of the wall resulting from the moments at the top and bottom of the wall, including any load applied eccentrically to the face of the wall (see Figure 7)
- N<sub>md</sub> = design value of the vertical load at the mid-height of the wall, including any load applied eccentrically to the face of the wall
- $e_{\rm hm}$  = the eccentricity at mid-height resulting from horizontal loads

A sub-frame analysis may be used as a simplified method for obtaining the moments at the top and bottom of vertically loaded walls, as given in Annex C in Part 1-1 of Eurocode 6.

### Table 3

#### Stiffness coefficient, $\rho_{\rm t}$ , for walls stiffened by piers

Ratio of pier spacing (centre to centre) to pier	Ratio of pier thickness to actual thickness of wall to which it is bonded		
width	1	2	3
6	1.0	1.4	2.0
10	1.0	1.2	1.4
20	1.0	1.0	1.0
Note			

Linear interpolation is permitted in this Table.

### Capacity reduction factors

At the top or bottom of the wall, the reduction factor for slenderness and eccentricity is given by:

$$\boldsymbol{\Phi}_{\rm i} = 1 - 2\frac{\rm e_{\rm i}}{\rm t}$$

where

- ${oldsymbol \Phi}_{
  m i}$  = reduction factor at the top or bottom of the wall
- $e_i$  = eccentricity at the top or bottom of the wall
- t = thickness of the wall

A method for calculating a capacity reduction factor at the mid-height of the wall,  $\Phi_m$ , is given in Annex G of Eurocode 6, Part 1–1, which simplifies the principles given in Cl. 6.1.1. This is shown graphically in Figure 8, which shows the corresponding capacity reduction factors for different values of slenderness and eccentricity for an elastic modulus 1000  $f_k$ , which is the value recommended in the UK NA.

The least favourable value of  $arPsi_{
m i}$  and  $arPsi_{
m m}$  should be used to calculate  $N_{
m Rd}$ .

## Vertical load resistance of solid walls and columns

The design resistance of a single-leaf wall per unit length,  $N_{\rm Rd}$ , is given by the following:

 $N_{\rm Rd} = \Phi t f_{\rm d}$ 

where

 $\Phi$  = capacity reduction factor allowing for the effects of slenderness and eccentricity of loading



### Moments from calculation of eccentricities



t =thickness of the wall

 $f_{\rm d}$  = design compressive strength of the masonry  $(f_{\rm k}/\gamma_{\rm M})$ 

For sections of small plan area, less than 0.1  $\rm m^2, f_d$  should be multiplied by (0.7 + 3A)

where

A = loadbearing horizontal cross-sectional area of the wall in m<sup>2</sup>

In the case of a faced wall, the wall may be designed as a single-leaf wall constructed entirely of the weaker material with a longitudinal joint between leaves.

A double-leaf (collar-jointed) wall may also be designed as for a single-leaf wall provided that the leaves are tied together adequately and both leaves carry similar loads and the cavity does not exceed 25 mm, or it may be designed as a cavity wall with one leaf loaded.

In the case of cavity walls, check each leaf separately using a slenderness ratio based on the effective thickness of the wall.

### **Concentrated loads**

For a Group 1 unit (not shell bedded) the vertical load resistance is:

 $N_{\text{Rdc}} = \beta A_{\text{b}} f_{\text{d}}$ where  $\beta = \left(1 + 0.3 \frac{a_1}{h_c}\right) \left(1.5 - 1.1 \frac{A_{\text{b}}}{A_{\text{ef}}}\right)$ 

 enhancement factor for load that should not be less than 1.0 nor taken to be greater than:

$$1.25 + \frac{a_1}{2h_c}$$
 or 1.5, whichever is the lesser

Figure 8 Capacity reduction factor,  $\varPhi_{\rm m}$  at the mid-height of the wall



- *a*<sub>1</sub> = distance from the end of the wall to the nearer edge of the loaded area
- $h_c$  = height of the wall to the level of the load
- $A_{\rm b}$  = loaded area
- $A_{\rm ef}$  = effective area of the bearing  $l_{\rm efm} t$
- l<sub>efm</sub> = effective length of the bearing as determined at the mid-height of the wall or pier
- *t* = thickness of the wall, taking into account the depth of recesses in joints greater than 5 mm wide

 $A_{\rm b}/A_{\rm ef} \le 0.45$ 

The enhancement factor,  $\beta$ , is shown graphically in Figure 9.

For walls built with Groups 2, 3 and 4 masonry units and when shell bedding is used, it is necessary to check that, locally under the bearing of a concentrated load, the design compressive stress does not exceed the design compressive strength of the masonry,  $f_d$  (i.e.  $\beta$  is taken to be 1.0).

In any case, the eccentricity of the load from the centre line of the wall should not be greater than t/4 as shown in Figure 10.

In all cases where a concentrated load is applied, the requirements for vertical load design should be met at the mid-height of the wall below the bearings. Account should be taken of the effects of any other superimposed vertical loading, particularly where concentrated loads are sufficiently close together for their effective lengths to overlap.

The concentrated load needs to bear on a Group 1 unit or other solid material. The length of this unit or bearing should equal the required bearing length plus a length on each side of the bearing based on a 60° spread of load to the base of the solid material. For an end bearing the extra length is required on one side only.

#### Figure 9



The concentrated load may be applied through a spreader beam of adequate strength and stiffness that has a width the same as the wall thickness, a height greater than 200 mm and a length greater than three times the bearing length of the load. In this case the design value of compressive strength beneath the concentrated load should not exceed  $1.5f_{\rm d}$ .

### Walls subject to shear forces

The design value of shear resistance is given by:

$$V_{\rm Rd} = f_{\rm vd} t l_{\rm c}$$

where

- $V_{\rm Rd}$  = the design value of shear resistance of the wall
- $f_{\rm vd}$  = the design value of the shear strength of the masonry (the characteristic shear strength divided by the partial factor for masonry,  $\gamma_{\rm M}$ ) based on the average vertical stresses over the compressed part of the wall that is providing the shear resistance
- t = the thickness of the wall resisting the shear
- $l_{\rm c}$  = the length of the compressed part of the wall, ignoring any part of the wall that is in tension

In calculating  $l_c$  assume a linear distribution of the compressive stress, take into account openings, etc. and do not include any area of the wall subjected to vertical tensile stresses.

### Effect of chases

Eurocode 6 recognises that chases and recesses should not impair the stability of a wall and provides appropriate guidance. Further explanation is given in the third guide in this series, *Lateral resistance*<sup>3</sup>.

### Figure 10

#### Walls subjected to concentrated load



### Selected symbols

### Symbol Definition

Symbol	Definition	Symbol	Definition	
A	Loadbearing horizontal cross-sectional area of the wall in m <sup>2</sup>		Effective length of the bearing as determined at the mid-height of the	
a <sub>1</sub>	Distance from the end of the wall to the nearer edge of the loaded area		wall or pier	
A <sub>b</sub>	Loaded area		Design value of the bending moment at the top or the bottom of the wall resulting from eccentricity of the floor load at the support	
A <sub>ef</sub>	Effective area of the bearing Eccentricity of the top or bottom of the wall resulting from horizontal loads		Design value of the greatest moment at the mid-height of the wall resulting from the moments at the top and bottom of the wall, including any load applied eccentrically to the face of the wall	
e <sub>he</sub>				
e <sub>hm</sub>	Eccentricity at the middle of a wall, resulting from horizontal loads	N <sub>id</sub>	Design value of the vertical load at the top or the bottom of the wall	
e <sub>i</sub>	Eccentricity of the wall		Design value of the vertical load at the mid-height of the wall,	
e <sub>init</sub>	Initial eccentricity		including any load applied eccentrically to the face of the wall.	
em	Load eccentricity	N <sub>Rd</sub>	Design resistance of a single-leaf wall per unit length	
e	Eccentricity at the mid-height of the wall	N <sub>Rdc</sub>	Design vertical load resistance to a concentrated load	
fL fL	Normalized mean compressive strength of a masonry unit	t	Thickness of the wall	
/ <u>Б</u> f.	Design compressive strength of the masonry in the direction being	t <sub>1</sub>	Effective thickness of the outer or unloaded leaf	
/d	considered		Effective thickness of the of the inner or loaded leaf	
$f_{\rm m}$	Compressive strength of the mortar	t <sub>ef</sub>	Effective thickness	
$f_k$	Characteristic compressive strength of the masonry, in N/mm <sup>2</sup>	t <sub>min</sub>	Minimum thickness of loadbearing wall	
f <sub>vk</sub>	Characteristic shear strength of masonry	V <sub>Rd</sub>	Design value of shear resistance of the wall	
f <sub>vd</sub>	Design value of the shear strength of the masonry	V	Notional inclination angle to the vertical	
g	Total of the widths of the mortar strips	lpha and $eta$	Constants to be used with Equation $(3.1)$ of Eurocode 6, Part 1–1	
h	Clear storey height of the wall	$\beta$	An enhancement factor for concentrated load	
h <sub>c</sub>	Height of the wall to the level of the load		Capacity reduction factor allowing for the effects of slenderness and	
h <sub>ef</sub>	Effective height of the wall	eccentricity of loading		
$\overline{h_{\text{tot}}}$	Total height of the structure	$\gamma_{M}$	Partial factor for a material property	
K	Constant to be used with Equation (3.1) of Eurocode 6, Part 1–1		Reduction factor, where $n = 2$ , 3 or 4, depending upon the edge restraint or stiffening of the wall	
l <sub>c</sub>	Length of the compressed part of the wall, ignoring any part of the wall that is in tension.	$ ho_{\mathrm{t}}$	Stiffness coefficient	

### References

- BRITISH STANDARDS INSTITUTION. BS EN 1996: Eurocode 6 Design of masonry structures. BSI (4 parts). 1
- 2 ROBERTS, JJ & BROOKER, O. How to design masonry structures to Eurocode 6: Introduction to Eurocode 6. The Concrete Centre, 2007.
- ROBERTS, JJ & BROOKER, O. How to design masonry structures to Eurocode 6: Lateral resistance. The Concrete Centre. 2007. 3
- BRITISH STANDARDS INSTITUTION. BS EN 772-1: Methods of test for masonry units Determination of compressive strength. BSI, 2000. 4

Charles Goodchild

Gerry Pettit

John Roberts

BRITISH STANDARDS INSTITUTION. BS EN 1052-1: Methods of test for masonry - Determination of compressive strength. BSI, 1999. 5

### Members of the steering group

Ali Arasteh	Brick Development Association
Owen Brooker	The Concrete Centre
Ken Fisher	International Masonry Society
Cliff Fudge	Aircrete Products Association

For more information on Eurocode 6 and other questions relating to the design, use and performance of concrete units, visit www.eurocode6.org or contact the free National helpline on:

0845 812 0000 helpline@concretecentre.com For queries on clay units contact the Brick Development Association on:

01344 885651 brick@brick.org.uk

### **Published by The Concrete Centre**

Riverside House, 4 Meadows Business Park, Station Approach, Blackwater, Camberley, Surrey GU17 9AB

The Concrete Centre

Consultant

Concrete Block Association

Tel: +44 (0)1276 606800 Fax: +44 (0)1276 606801

www.concretecentre.com

### Acknowledgement

This publication was jointly funded by the Modern Masonry Alliance and The Concrete Centre.



#### www.modernmasonry.co.uk



The **Concrete** Centre<sup>™</sup>

Ref<sup>.</sup> TCC/03/36 ISBN 978-1-904818-57-1 First published December 2007, revised January 2009 Price Group M © The **Concrete** Centre<sup>™</sup>

All advice or information from The Concrete Centre (TCC), and the Modern Masonry Alliance (MMA) is intended only for use in the UK by those who will evaluate the significance and limitations of its contents and take responsibility for its use and application. No liability (including that for negligence) for any loss resulting from such advice or information is accepted by TCC and MMA or their subcontractors, suppliers or advisors. Readers should note that publications from TCC and MMA are subject to revision from time to time and should therefore ensure that they are in possession of the latest version.